

Bar Closure Process – Blowing Lines



- Disconnect all keg couplers, clean and sanitise
- Clean the cleaning sockets
- Attach couplers to the cleaning ringmain
- Clean the lines in normal way and rinse with water
- Leave fobs in cleaning mode*
- Ensure the cleaning bottle is empty and line cleaning feed tube is inside the bottle
- At the bar, open each tap until air is coming through every line. If in doubt, keep tap open for 30+ seconds. This will not damage the assist pump
- Turn off cleaning gas and any assist pumps
- Turn off remote coolers at the plug **
- Turn gas off at individual valves and main supply



* Above: Fob pin taped up in cleaning mode

*If the pin drops in the fob chamber (sealing the line), water will be left in the line. You will need to tape the pin in the 'up' or 'cleaning mode' position

** This will most likely result in the reservoir leaking from the overflow pipe. You may want to position a bucket there to collect spillage